

# Table of Contents

## **Section 1 - Preparing for ThermoForm System**

---

Tool List	1
Basic Components	2
Locating Components	3
Plastic 90° Corner Set	4
Plastic 45° Corner Set	5
Wall Width Dimensions	6

## **Section 2 - 90° Corner Assembly**

---

Mounting Lower C-Channel	7
Placing Outside Plastic Corner & Corner Panels	8
Placing Inside Plastic Corner & Plastic Studs	9
Securing C-Channel to Outside Plastic Corner & Plastic Studs	10
Installing Corner Rebar	11

## **Section 3 - Straight Wall Assembly**

---

Placing Vertical Poly Panels with Plastic Studs	12
Mounting Upper C-Channel	13
Using Temporary Bracing	14
Required Bracing	15

## **Section 4 - Bracing Corners**

---

Installing Corner Post & Angle Braces	16
Installing Lap Boards	17
Installing Horizontal Walers & Lap Boards	18
8ft & 9ft Completed Corner Bracing	19
10ft - 12ft Corner Bracing	20
Custom Angled Corner Bracing	21

## **Section 5 - Building Techniques**

---

Installing Horizontal Rebar	22
Installing Vertical Rebar	23
Securing Upper C-Channel Building	24
T-Intersection	25
Bracing T-Intersection	26
Installing a TF Systems Brick Ledge	27
Installing a Common Brick Ledge	28
Building a Corner with Brick Ledge	29-31
Building an Offset Wall	32-33
Building a Circular Wall	34-35
Building Window Buck Frame	36

Installing Felt Paper & Upper C-Channel	37
Cutting Spliced Poly Panels for Window Buck	38
Placing Completed Window Buck into Wall	39
Building Header on top of Window Buck	40
Building Door Buck Frame	41
Installing Anchor Bolts	42
Installing Felt Paper & Upper C-Channel	43
Placing Completed Door into Wall	44
Building Header on top of Door Buck	45

## **Section 6 – Bracing Overview**

---

Use Common Sense	46
Interior Bracing Overview	47
Exterior Bracing Overview	48
Standard Wood Kicker Assembly	49
Standard Wood Kicker Installation	50
Common Mistakes with Kickers	51
Common Mistakes with Kickers Cont.	52
Using a Turnbuckle	53

## **Section 7 - Pouring Concrete**

---

Pre-Pour Checklist	54
Concrete Placement	55
Concrete Consolidation	56
Pouring Around Windows	57
Pouring Around Windows Cont.	58
Pouring Example	59
Repairing a Blowout - Diagram	60
Repairing a Blowout - Instructions	61
After the Pour	62
Day After the Pour (Window Buck)	63
Installing Window Unit	64
Installing Door Unit	65

## **Section 8 - Best Practices**

---

Building a Dry Basement (Instructions)	66
Building a Dry Basement (Diagram)	67

## **Section 9 – Floor Connection Details**

---

Ledger Board Detail - Using Simpson™ ICF Connectors	68
Ledger Board Detail - Any Combination of Wall Width	69
Bearing Ledge Detail - 10" to 6" ThermoForm Wall	70
Stick Wall Detail - Stick Wall on 8" ThermoForm Wall	71

## **Section 10 – Subcontractor**

---

Attaching Drywall or Cladding to Interior Return Corner	72
Attaching Drywall to Interior Corner	73
Attaching Siding	74
Installing Penetrations	75
Installing Plumbing	76
Installing Electrical	77
Disclaimer	78